

REDBACK ENVIRO PRODUCT WARRANTY CERTIFICATE

Warranty No. _____

IMPORTANT: THIS MUST BE FILLED IN & RETURNED *NOW!*

WHOLESALER NAME: _____
KEY CONTACT NAME: _____
ADDRESS: _____
CITY: _____ STATE: _____
POSTCODE: _____ PHONE: _____
SWD INVOICE #: _____

INSTALLER BUSINESS NAME: _____
ADDRESS: _____
CITY: _____ STATE: _____
POSTCODE: _____ PHONE: _____
Installer Name (print name): _____
Signature: _____ Date: ____ / ____ / ____

*This Warranty Certificate must be sent back to SWD AUST prior to any warranty claim and for this product to be eligible for warranty in the future.
**All details must be filled out in full to make this a valid warranty certificate.
Please return to:
SWD AUST 122-124 Compton Road, Woodridge 4114 QLD
For all warranty enquiries please call: **1300 493 884**

VEHICLE MAKE: _____ MODEL: _____
YEAR: _____ ODOMETER: _____ ENGINE SIZE: _____ L
FUEL TYPE: _____ REGO #: _____
(91, 95, 98, ETHANOL, DIESEL, BIO DIESEL)
OIL BRAND: _____ OIL VISCOSITY: _____
LAST SERVICE DATE: ____ / ____ / ____ KM AT LAST SERVICE: _____
PRODUCT SERIAL #: _____ PRODUCT PART #: _____
(STAMPED ON THE PART)

NEW GASKETS FITTED (e.g. CKIT, OEM)? Y N
(PLEASE TICK ONE)
REPLACED ALL SENSORS (O², Pressure, etc)? Y N
(PLEASE TICK ONE)
WERE YOU GIVEN & DID YOU READ THE ***"DPF TRAINING GUIDE"***
BEFORE REPLACING THE DPF? Y N
(PLEASE TICK ONE)
DATE PART FITTED: ____ / ____ / ____

PLEASE INCLUDE ALL INFORMATION ABOUT WHAT HAPPENED TO THE DPF / CAT & BACKGROUND INFORMATION ON THE VEHICLE.

REDBACK ENVIRO PRODUCT WARRANTY CERTIFICATE

STOP!!

BEFORE INSTALLING THIS CATALYTIC CONVERTER / DPF

- A COMPLETE EVALUATION OF THE EXHAUST SYSTEM FOR DAMAGE AND / OR CONTAMINATION MUST BE DONE BEFORE REPLACING THE CATALYTIC CONVERTER / DPF.
- ENSURE THE ORIGINAL ENGINE FAULT HAS BEEN RECTIFIED BEFORE REPLACING THE CATALYTIC CONVERTER / DPF.
- THE “DPF TRAINING GUIDE” MUST BE READ & UNDERSTOOD BEFORE REPLACING ANY DPF.

CATALYTIC CONVERTER FITMENT

- Replace all gaskets, bolts and mountings.
- It is strongly recommended to replace all oxygen sensors on the Catalytic Converter.
- Do not use exhaust paste or silicone sealant upstream of the Catalytic Converter.
- After fitment run the vehicle at 2500rpm until the electric fan kicks in. Run the vehicle for another 1 minute until the Catalytic Converter temperature reaches 350°C.

DPF FITMENT

- Change the engine oil when replacing a DPF. Only use the manufacturers specification oil.
 - Replace all gaskets, bolts and mountings.
 - It is strongly recommended to replace all sensors on the DPF.
 - Do not use exhaust paste or silicone sealant upstream of the DPF.
 - Do not run the vehicle on biodiesel
 - **YOU MUST** update the engine management software to tell the vehicle it has a new DPF fitted.
 - **YOU MUST** run a forced Regen on the new DPF
- BEFORE DRIVING THE VEHICLE**



FAILURE TO FOLLOW THE ABOVE WILL VOID THE WARRANTY
All Catalytic Converters & DPF's are sold subject to warranty conditions
found at www.swd.com.au or Phone 1300 493 884. © 2017 SWD AUST.